

# How to shorten your 5005 Heavy Duty Drawer Slides

We recommend the use of a fine cut off disc. The same amount must be cut from each end.

Using a square, mark a line around the channel

Cut the desired amount from the sliding channel here

Drill any mounting holes needed

Using a square, mark a line around the channel

Cut the desired amount from the fixed channel here

Re-drill the stop fixing holes and attach the stop as shown

If using with the 4364 Push Button Drawer Handle, cut new stop slot to fit.

© Comac 2017. All rights reserved. Associated patents and trade marks are the property of Comac Limited.



(+64 6) 350 0015  
orders@comac.co.nz